

TABLE OF CONTENTS

<u>INTRODUCTION</u>	<u>Page No.</u>
Warning	3
Guarantee	4
Replacement of Parts	5
List of Illustrations and Drawings	8
<u>I GENERAL CHARACTERISTICS</u>	
1. Equipment	9
2. Tube Complement	9
3. General Description	9
4. Type of Emission	9
5. Frequency Range	9
6. Frequency Change Method	9
7. Power Output	9
8. Power Source and Input Requirements	10
9. Controls	10
10. Accessories	10
<u>II INSTALLATION</u>	
11. Uncrating	11
12. Inspection	11
13. Placing Transmitter	11
14. Fuses	11
15. External Connections	11
<u>III PRELIMINARY ADJUSTMENT</u>	
16. Preliminary	13
17. Tubes	13
18. Coils and Crystals	13
19. Radio Frequency Circuit Adjustment	15
<u>IV CIRCUIT DESCRIPTION</u>	
20. Control Circuits	19
21. Keying Circuit	19
22. Channel Selector System	19
23. Power Supplies	19
24. Audio System	19
25. Radio Frequency Section	19
<u>V MAINTENANCE</u>	
26. Routine Inspection	21
27. Cleaning	21
28. Relays	21
29. Fuses	21
30. Crystals	21
31. Removal of Units	21
32. Trouble Shooting	22

TABLE OF CONTENTS

<u>VI APPENDIX</u>	<u>Page No.</u>
Performance Data	24
Parts Lists	26
Spare Parts List	37
List of Manufacturers	39
Photographic Illustrations	40
Cable Wire Code for Wiring Diagrams	46
Service Report Blanks	47
Drawings	51

LIST OF ILLUSTRATIONS AND DRAWINGS

<u>PHOTOGRAPHIC ILLUSTRATIONS</u>	<u>Fig.</u>	<u>Page No.</u>
32RA Transmitter and Accessories	1	8
32RA Transmitter—Top View	2	40
32RA Transmitter—Rear View	3	41
32RA Transmitter—Bottom View	4	42
33K R-F Unit—Top View	5	43
33K R-F Unit—Bottom View	6	43
9Z Modulator Unit—Top View	7	44
9Z Modulator Unit—Bottom View	8	44
411B Power Unit—Top View	9	45
411B Power Unit—Bottom View	10	45

<u>DRAWINGS</u>	<u>Dwg. No.</u>	<u>Page No.</u>
Coil Tuning Data		17
7000C-5 Coil Unit Schematic	102A	51
32RA-8 Complete Transmitter Schematic	1275C	52
32RA-8 Cabling Schematic	622D	53
69H-1 Handset Schematic	1580A	51
33K-9 R-F Unit, Practical Wiring Diagram	531D	54
101L-7 Panel, Practical Wiring Diagram	1154C	55
411B-4 Power Supply, Practical Wiring Diagram	1152C	56
9Z-8 Modulator, Practical Wiring Diagram	572D	57